



WILDLIFE FEEDERS

HANGING FEED CONTAINER -INSTRUCTIONS

▲ WARNINGS: To prevent serious injury or death:

- 1. Assemble this hanging feed container with the supplied hardware only.**
- 2. Never put more than 200 pounds of feed in this feed container.**
- 3. Never walk under any hanging feeder, support cable, or tripod.**
- 4. Discontinue use if any part is excessively worn or broken.**
- 5. Wear gloves to protect hands from sharp metal edges.**
- 6. Check all hardware and brackets before each use.**

ASSEMBLY:

- 1. Locate the 24-gallon feed container, cover, overhead support bracket, and mounting hardware.**
- 2. Remove the feed container cover and place it in a safe location.**
- 3. Hold support bracket over the open end of the feed container, and align the four mounting holes in the bracket with the four holes in the sides of the feed container.**
- 4. Insert the bolts into the support bracket, then into the sides of the feed container. The two short bolts go into top holes and the two long bolts go into the bottom holes.**
- 5. Reach inside the feed container, and place a flat washer then a lock nut onto each bolt. Tighten the lock nuts by hand**
- 6. Using the proper tools, tighten the four (4) locknuts onto each of the four bolts equally until they “touch” the inside of the feed container.**

IMPORTANT: Do NOT tighten the bolts all the way. This will deform the feed container and not allow the cover to fit.

- 7. The nuts should be tightened until the support bracket can no longer slide back and forth on the four bolts without deforming the feed container.**
- 8. Mount any of the Spinpro feeders to this feed container with the instructions included with the feeder.**
- 9. Fill the feed container with the desired feed, (200 pounds maximum) replace the cover, then safely hang where required.**